



SOLAR RIG 4 COLOR STROBE LIGHT

Pattern Selection

Choose from thirty one different Flash Patterns shown to your right.

Briefly press (1 second) the Program button to advance the flash pattern forward by one.

Press the SL program button down for (3 seconds) to revert to the default pattern which is (flash pattern 1 - steady).

Color Combination Selection

Choose from fifteen different single, dual, tri, and a quad color Patterns shown below.

Quickly press the Program button consecutively 3 times to change the color combination.

Press the SL Program button down for 8 seconds to reset the color combination to the default combination which is (quad color).

Flash Patterns	
1	Steady (Default)
2	Quintuple I
3	Consecutive Quintuple I
4	Quad
5	Consecutive Quad
6	Double - Slow
7	Consecutive Double - Slow
8	Single
9	Consecutive Single
10	Triple - Slow
11	Consecutive Triple - Slow
12	Quintuple II
13	Consecutive Quintuple II
14	Double - Medium
15	Consecutive Double - Medium
16	Single - Slow
17	Consecutive Single - Slow
18	Single - Moderate
19	Consecutive Single - Moderate
20	Single - Medium
21	Consecutive Single - Medium
22	Single - Fast
23	Consecutive Single - Fast
24	Single - Hyper
25	Consecutive Single - Hyper
26	Double - Fast
27	Triple - Fast
28	Quad + Single - Moderate
29	Quad + Single - Fast
30	Twinkle
31	Combo

Specification Overview	
Voltage (DC)	9V to 30V
Operating Temperature	-34 to 158 F
LED Color	Amber/White/Blue/Red

